



Bell & Gossett Isolation Flange and Check-Trol® User Guide

Isolation flanges		Use with the following circulators			
Part number	Sizes	Bell & Gossett	Taco ①	Grundfos ②	Armstrong ③
101221LF	3/4" NPTI	ecocirc® 20-18 and ecocirc+ 20-18, ecocirc XL 20-35, 36-45, 55-45, NRF/NBF/SSF, Wet Rotors*, Series PL-30, PL-36, PL-55, PL-100, Series 100, PR and LR, 601, 602, 603, 604, 605, 606	005, 006, 007, 008, 009, 0010, 0011, 0013, 0014, 110, 111, 112, 113, 007e, 0015e, 0018e, VR1816, VT2218	UP15-42, UP26-64, UP26-99, UP15-58, UP26-96, UPSe, Alpha2 15-55SF, Alpha 15-58, UPS43-44, UPS15-35	Astro 30, Astro 50, S-25, H-41, E7, E8, E9, H-51, H-52, 1050-1B, 1050-1 1/4B, Compass H, Astro2
101222LF	1" NPTI				
101223LF	1 1/4" NPTI				
101241LF	1 1/2" NPTI				
101226LF	3/4" Sweat				
101227LF	1" Sweat				
101228LF	1 1/4" Sweat				
101243LF	1 1/2" Sweat				
101255LF	3/4" Press				
101256LF	1" Press				
101257LF	1 1/4" Press				
101258LF	1 1/2" Press				

*Not for use with NRF/NBF 45.

Bell & Gossett Isolation Flange and Check-Trol® User Guide

Check-Trol		Use with the following circulators			
Part number	Sizes	Bell & Gossett	Taco ①	Grundfos ②	Armstrong ③
101231LF 101232LF 101233LF 101245LF	3/4" NPTI 1" NPTI 1 1/4" NPTI 1 1/2" NPTI	ecocirc 20-18 and ecocirc* 20-18, ecocirc XL 20-35, 36-45, 55-45, NRF/NBF/SSF, Wet Rotors*, Series PL-30, PL-36, PL-55, PL-100, Series 100, PR and LR, 601, 602, 603, 604, 605, 606	005, 006, 007, 008, 009, 0010, 0011, 0013, 0014, 110, 111, 112, 113, 007e, 0015e, 0018e, VR1816, VT2218	UP15-42, UP26-64, UP26-99, UP15-58, UP26-96, UPSe, Alpha2 15-55SF, Alpha 15-58, UPS43-44, UPS15-35	Astro 30, Astro 50, S-25, H-41, E7, E8, E9, H-51, H-52, 1050-1B, 1050-1 1/4B, Compass H, Astro2
101236LF 101237LF 101238LF 101247LF	3/4" Sweat 1" Sweat 1 1/4" Sweat 1 1/2" Sweat				
101251LF 101252LF 101253LF 101254LF	3/4" Press 1" Press 1 1/4" Press 1 1/2" Press				

① Taco is a registered trademark of Taco, Inc. | ② Grundfos is a registered trademark of Grundfos Pumps Corp. | ③ Armstrong is a registered trademark of S.A. Armstrong Limited.

*Not for use with NRF/NBF 45.

Notes: 601, 602, 603, H-51, 1050-1B use 1" flanges | 604, 605, 606, H-52, 1050-1 1/4B use 1 1/4" flanges

Xylem Inc.
8200 N. Austin Avenue
Morton Grove, Illinois 60053

Phone: (847) 966-3700
Fax: (847) 965-8379
www.xylem.com/bellgossett

Subject to change without notice. All information presented herein is believed reliable and in accordance with accepted engineering practices. Xylem makes no warranties as to the completeness of this information. Users are responsible for evaluating individual product suitability for specific applications. Xylem assumes no liability whatsoever for any special, indirect or consequential damages arising from the sale, resale or misuse of its products.

© 2025 Xylem and Bell & Gossett are trademarks of Xylem, Inc. or one of its subsidiaries. All other trademarks are the property of their respective owners.

BG-UG FHD-18E 10/2025

xylem
Let's Solve Water